## Procedure of changing the Luftmy Sensor

## model: PUV310C(8126AS)





## Luftmy Sensor


Tools







electrostatic bracelet (Better to ware)



Can use a flat screw driver to help peal of the panel





图1         ●	图2       ●    ●       ●       ●       ●       ●       ●       ●       ●       ●       ●       ●       ●       ●       ● <t< th=""><th>图3   Image: Wight of the second se</th><th></th></t<>	图3   Image: Wight of the second se	
Remove the 3M tape.	Unscrew the 2 screws from the sensor holder	Take off the sensor holder	Unpluy the sensor connector






Take away the sensor.



Make sure it fix tight.


Fix the sensor holder with 2 screws.

Pull stright the sensor cord and stick back the 3M tape.




Fix the top housing back to the unit. Pay attentin to the gap for right direction.

Fix the outlet back to the unit, pay attention to the step for right direction.





Fix the holder back to the unit, pay attention to the step for right direction.



Plug in above five connectors.

8







Fix the top part back the unit. Make sure the direction is right.

Stick tight the touch panel.

